



# OPEN SEA

Explore • Escape • Experience



Before you get on board on one of our fully equipped, spacious and unique Ribs please make sure you have read all the necessary information in order to enjoy a safe and pleasure trip!



## GA7 [SCORPION 100G2]

### SPECIFICATIONS:

Length Overall: 10.50m  
Beam (maximum): 3.20m  
Draft: 0.9 m  
Displacement: 3000kg  
Year: 2009  
Builder: Ribco Marine  
Pax: 10  
Cabins: 0

### PERFORMANCE:

Engines: 2x Suzuki 300Hp  
Type: Outboard  
Fuel Type: Gasoline  
Fuel Capacity: 900lt  
Fresh Water Capacity: 160lt  
Cruising Speed: 35Kn  
Maximum Speed: 52Kn  
Fuel Consumption: 90lt/h (35Kn)

**EQUIPMENT:** 10 inch GPS plotter & sonar, Fusion MP3 player, Polk audio amplifier, 4 speakers, VHF, anchor winch, sun cover, sundeck, fresh water with shower, fridge, ice box-igloo

**GENERAL INFORMATION**

Main Power Switch	Compartment right of the wheel
Windlass Main Fuse	Compartment front of the helm
Windlass Up&Down Switch	1st Button from the left
Service Main Fuse	Compartment right of the wheel
Fuse case	Compartment right of the wheel
Fuel Valve (tank select)	Rear compartment (on the right)
Fuel Fill	At the deck (1 bow & 1 stern) & 1 at Helm
Water Fill	At the deck 2 plugs at bow
Fuel Tank & Capacity	3 X (290lt + 340lt + 250lt) , Total : 880 litres
Water Tank & Capacity	2 X 80 litres, Total: 160 litres
Cruising Speed	35 knots
Maximum Speed	52 knots
Draft	0.9 meters
Auxiliary Engine Portable Tank	Not Included
Spare Anchor	Rear compartment
Ice Box	Rear compartment

**EQUIPMENT - LIFE SAVING**

Fenders	Rear compartment
Ropes	Below the back seat, left compartment
Hook	Rear compartment
Life Jackets	Rear compartment (white bag)
Ring Lifebuoy	Rear compartment
Floating Device	Rear compartment
Floating Anchor	Rear compartment (white bag)
Flairs	Rear compartment (white bag)
Smoke Agent	Rear compartment (white bag)
Fire Extinguisher	Below the back seat, right compartment
Pump	Below the back seat, right compartment
Bucket	Below the back seat, right compartment
Toolkit	Rear compartment (white box)
Spare fuses	Rear compartment (white box)
Tortch	Rear compartment (white box)
First Aid Kit	Rear compartment (white box)
Jackknife	Rear compartment (white box)
Winchandle	Rear compartment (white box)

**BUTTON FUNCTIONS**

Button	Function
1st	Anchor
2nd	Spare
3rd	Blidge Pump
4th	Fresh Water Pump
5th	Navigation Lights & Button Lights
6th	Spare
7th	Anchor Light
8th	Stern Lights
9th	Deck Lights
10th	Horn

\*The numbering of the buttons are from left to the right.

**SAFETY INSTRUCTIONS FOR THE CAPTAIN**

1. Embarkation & disembarkation only when boat is fully stoped
2. Start the engine only when at full control of the boat and seated
3. Make sure that you are aware of safety equipment's location before departure
4. Always wear the Quick Stop Cord at hand or leg when cruising
5. Warm up the engine 5 minutes at start
6. Never use the swimming ladder when the engine is running
7. Attach the anchor to boat with safety-wire before departure
8. Trim the engine at lowest position to plan the boat
9. Use the trim switch in order to optimize cruising and fuel consumption. Ask our crew for optimum trim instructions
10. Enter and exist the marina at 3 knots maximum
11. Use VHF channel 16 at emergency
12. Keep 200 meter safety distance from the last swimmer
13. Stay out of the buoys at restricted areas
14. Close the main power switch when leaving the boat
15. Turn the main power switch at combine only at emergency
16. Do not let the service batteries discharge below 10,5 V