



OPEN SEA

Explore • Escape • Experience



Before you get on board on one of our fully equipped, spacious and unique Ribs please make sure you have read all the necessary information in order to enjoy a safe and pleasure trip!



KINAROS [SKIPPER 780S]

SPECIFICATIONS:

Length Overall: 8.10 m
Beam (maximum): 2.75 m
Draft: 0.6m
Displacement: 1900 kg
Year: REBUILT 2017
Builder: SKIPPER-SKIPPER-BSK
Pax: 10
Cabins: 0

PERFORMANCE:

Engines: 1x Suzuki DF 250HP & Auxiliary 9,9Hp
Type: Outboard
Fuel Type: Gasoline
Fuel Capacity: 380lt
Fresh Water Capacity: 120lt
Cruising Speed: 30Kn
Maximum Speed: 41Kn
Fuel Consumption: 50lt/hr (30Kn)

EQUIPMENT: 7 inch GPS plotter & sonar, MP3 player, VHF, anchor winch, sun cover, fresh water with shower, ice box

**GENERAL INFORMATION**

Main Power Switch	Compartment at the right side of the Helm
Windlass Main Fuse	Compartment at the right side of the Helm
Windlass Up&Down Switch	Left of the wheel
Service Main Fuse	Not included
Fuse case	Under the plastic cover of the Button panel
Fuel Valve (tank select)	Rear Compartment (on the right)
Fuel Fill	Front Right Compartment
Water Fill	On the right of the stern
Fuel Tank & Capacity	1 X 380 litres
Water Tank & Capacity	1 X 120 litres
Cruising Speed	32 knots
Maximum Speed	42 knots
Draft	0.6 meters
Auxiliary Engine Portable Tank	Rear compartment
Spare Anchor	Rear upper left compartment
Ice Box	Front left compartment

EQUIPMENT - LIFE SAVING

Fenders	Rear upper right compartment
Ropes	Rear upper right compartment
Hook	Rear compartment
Life Jackets	Rear compartment (white bag)
Ring Lifebuoy	Rear compartment
Floating Device	Rear compartment
Floating Anchor	Rear compartment (white bag)
Flairs	Compartment under the helm (white box)
Smoke Agent	Compartment under the helm (white box)
Fire Extinguisher	Compartment under the helm
Pump	Compartment under the helm
Bucket	Compartment under the helm
Toolkit	Compartment under the helm (white box)
Spare fuses	Compartment under the helm (white box)
Tortch	Compartment under the helm (white box)
First Aid Kit	Compartment under the helm (white box)
Jackknife	Compartment under the helm (white box)
Winchandle	Compartment under the helm (white box)

BUTTON FUNCTIONS

Button	Function
1st	Horn
2nd	Navigation Lights
3rd	Anchoring Light
4th	Instruments
5th	Fresh Water Pump
6th	Bow Deck Lights
7th	Deck Lights
8th	Blidge Pump

*The numbering of the buttons are from left to the right.

SAFETY INSTRUCTIONS FOR THE CAPTAIN

1. Embarkation & disembarkation only when boat is fully stoped
2. Start the engine only when at full control of the boat and seated
3. Make sure that you are aware of safety equipment's location before departure
4. Always wear the Quick Stop Cord at hand or leg when cruising
5. Warm up the engine 5 minutes at start
6. Never use the swimming ladder when the engine is running
7. Attach the anchor to boat with safety-wire before departure
8. Trim the engine at lowest position to plan the boat
9. Use the trim switch in order to optimize cruising and fuel consumption. Ask our crew for optimum trim instructions
10. Enter and exist the marina at 3 knots maximum
11. Use VHF channel 16 at emergency
12. Keep 200 meter safety distance from the last swimmer
13. Stay out of the buoys at restricted areas
14. Close the main power switch when leaving the boat
15. Turn the main power switch at combine only at emergency
16. Do not let the service batteries discharge below 10,5 V